




















Step 4 - Conduit connectors

Connectors for extra flexible conduit
















Conduit	Compression	Press-on	In-Line	Union
 FC-X-SW	 A-10CS	<i>Attention!! You need a hydraulic press to mount these</i>	With 1/2" thread use to connect the wire guide modules	
 FC-X	 A-10CX	 A-11X	 A-10-XM	
 FC-XH	 A-10R	 A-11XH	 A-10RM	 A-10RU
 FC-XH-LW	 A9 + A6	 A-11XH-LW	 A-9	 A-9U

For connectors with a strain relief add -SR to the article number

Connectors for Extreme Flexible Conduit

Conduit	Compression	In-Line	Compression with Strain-relief
 FC-E	 A-10CH	 A-10HM	 A-10CH-SR

Connectors for polymer conduit

Conduit	Compression	Self-threading	In-Line	Union
 EC-3	 A-10CS		With 1/2" thread use to connect the wire guide modules	
 EC-4	 A-10CH	 A-16F4	 A-10HM	
 EC-5	 A-10R	 A-16F5	 A-10RM	 A-10RU
 EC-6	 A9 + A6		 A-9	 A-9U

For connectors with a strain relief add -SR to the article number

Replacement ferrules for compression connectors

Re-use the connector by only replacing the ferrule



A-9-FE



A-10RFE



A-10XFE



A-10CFE



A-10SFE

Conduit	Ferrule
FC-X-SW & EC-3	A-10SFE
EC-4	A-10CFE
FC-X	A-10XFE
FC-XH & EC-5	A-10RFE
FC-XH-LW & EC-6	A-9-FE